



**Firearm mode**

The firearm will be mentioned one time. To use the shooting simulator afterwards toggle the power off and on.

**Weapon selection**

If the battery voltage gets below approx 7 Volt, the shooting simulator will start you "Low battery" and stop working.

**Firearm mode**

If the Mode Button is pressed during action, the shooting simulator will stop and return to the previous mode.

**Weapon selection**

Pressing the button briefly correspond to "Fire", pressing and holding the button for a while will correspond to "Mag".